
The M7 RF Remote Control

FIRST USE

The M7 RF remote control is easy to use. It comes already paired to the controller. Make sure you remove the clear plastic battery protection sleeve sticking out of the base of the remote contrrol. This will allow the battery to provide power to the remote.



Pull this clear plastic tab out.

REPLACING THE BATTERY

The M7 remote uses a standard watch battery (CR2025). To remove the battery, turn the remote over. At the base of the remote you'll see a small door that slides into the bottom of the remote. Push the small tab toward the center of the remote while pulling downward on the door itself. The battery and battery cradle will slide out from the bottom. The positive side of the battery should be facing toward you when pulling the drawer out.



Pull drawer down

HOW TO PAIR THE REMOTE TO CONTROLLER


Typically the remote and the controller will stayed paired. If however you accidentally press the 'pairing' button on the controller, you will delete the pairing and have to pair your M7 remote to the controller. There might also be a situation where you want to add a second remote and you'll need to pair the new remote to the controller. Pairing the M7 remote to the controller is simple.

Step 1: Power up the controller. You can tell if the controller has power when the green power light is on.

Step 2: Quickly press the pairing button on the controller box and release. Do not hold down. When in pairing mode, the green power light will flash.

Step 3: With the controller in pairing mode, press and release any button on the M7 remote. As soon as you do this, the green flashing light on the controller should turn solid green. This means the M7 remote and the controller are now paired.

If you wish to pair a second M7 remote, repeat the pairing process.



The green power light will flash when in pairing mode.

USING THE REMOTE



POWER ON/OFF: The top left RED button is the power button. It turns the lights on and off.

COLOR: Press the + or - signs to change colors.

BRIGHTNESS: Press the + or - signs to increase or decrease brightness of your lights.

MODE: Press the + or - signs to change the mode. Solid on, strobbing, fading, color changing, breathing.

SPEED: Press the + or - signs to increase or decrease the speed of the feature.

RULE THE NITE™
BOOGEY LIGHTS®
Lighting Bikes Since 1989!

7505 Sussex Drive Suite 114, Florence, KY, 41042
www.boogeylights.com Phone: 800.847.1359

09-24-16