



## Operating your Value Series Multi-Color Remote

The On/Off button (upper left) is used to power your lights. The Color Selection button (upper right) is used to select between the seven different available colors. Press the Strobe button (bottom left) to make the selected color flash at varying speeds. Pressing the Fade button (bottom right) causes the selected color to fade in and out at varying speeds.

- Press the On/Off button once to turn ON the first color. In this "on" mode you can change the displayed color by pressing the Color Selection button.

- Click the color selection button to cycle through the colors until you come to solid red (only necessary if the color is not already displayed). From this point, you can click through the available solid colors until the eleventh press of the button. At that time, the colors will begin to blend together and slowly cycle through all of the colors automatically. To increase this blend, click the color selection button for the twelfth and thirteenth time. With the fourteenth click, you will return to solid red.

- Press the Strobe button one time to make the selected color go into a blinking motion. With each press of the Strobe button, the blinking will slow. On the fourth press, it will return to full speed.

- Press the Fade button one time to cause the selected color to fade in and out. The LEDs will dim slower with each press of the button, resetting to the original fade on the fourth click.

**\*\*NOTE:** This Value Series remote does not allow for the Breathing function, which is found on our Premium Series remote.\*\*

